

# Geothermics and Geothermal Energy

## Geothermal Heating Systems

Stefan Hergarten

Institut für Geo- und Umweltwissenschaften  
Albert-Ludwigs-Universität Freiburg



## Dependencies

The actual heating demand of a building depends on

- the thermal efficiency of the building
- the climatic conditions
- the number and the behavior of the residents.

## Data Requirements

**Fired heating systems** (oil, gas, biofuels, ...): long-term mean power (yearly) and peak power

**Geothermal and solar heating systems:** time-resolved data (e. g., on a monthly scale)

## Thermal Efficiency

The **U value** of an element of the building's surface (wall, window, ...) quantifies the heat flux density per temperature difference:

$$U = \frac{q}{T_i - T_o} \quad (1)$$

where

$q$  = heat flux density = power per area  $[\frac{W}{m^2}]$

$T_i$  = inside temperature [K]

$T_o$  = outside temperature [K]

Unit:  $\frac{W}{m^2K}$

## Thermal Efficiency

The *R value* of an element of the building's surface is

$$R = \frac{1}{U} = \frac{T_i - T_o}{q} = \frac{d}{\lambda} \quad (2)$$

for a homogeneous material of thickness  $d$  and thermal conductivity  $\lambda$ .

*Actual required heating power* for the entire building:

$$P = \sum_j q_j A_j = \left( \underset{\substack{\uparrow \\ \text{residents}}}{T_i} - \underset{\substack{\uparrow \\ \text{climate}}}{T_o} \right) \sum_j \underset{\substack{\uparrow \\ \text{building}}}{U_j} A_j \quad (3)$$

for  $T_i > T_o$  where the  $A_j$  are the surface areas of the elements.

## The Influence of Climate

Total energy required for heating during a given time span:

$$E = \int_{T_i > T_o} (T_i - T_o(t)) dt \sum_j U_j A_j \quad (4)$$

The integral

$$\text{HDD} = \int_{T_i > T_o} (T_i - T_o(t)) dt \quad (5)$$


for a fixed  $T_i$  (independent of the specific residents' behavior) is called **number of heating degree days** within the given time span.

Several slightly different ways of calculating the HDD.

## The Influence of Climate

Definition established in the EU:

- $T_i = 18^\circ\text{C}$
- Use mean temperatures over one-day periods for  $T_o$  instead of continuous time.
- Take into account only days below a heating threshold of  $15^\circ\text{C}$ .



Source: Global CCS Institute

## The Influence of Climate

Total energy required for heating during a given time span:

$$E = \text{HDD} \sum_j U_j A_j \quad (6)$$

- Obtained unit is W days.
- If the total energy demand,  $\sum E$ , and total HDD,  $\sum \text{HDD}$ , for one year are given instead of  $\sum_j U_j A_j$ :

$$E = \sum E \frac{\text{HDD}}{\sum \text{HDD}} \quad (7)$$

## Why?

Domestic heating systems require  $T \geq 35^\circ\text{C}$  (old systems even much more)



Cannot be achieved by shallow geothermal systems.



Temperature of the fluid in the heat exchanger must be increased using mechanical work.


## Principle

**Heat engine:** heat (hot reservoir)  $\rightarrow$  mechanical work + heat (cold res.)

**Heat pump:** heat (cold reservoir) + mechanical work  $\rightarrow$  heat (hot res.)



## Principle




Source: Geothermal heat-pump association of New Zealand

## Carnot Cycle and Inverse Carnot Cycle

Carnot cycle

Inverse Carnot cycle



Directions:

- isothermal expansion  
(coupled to large reservoir)
- ← isothermal compression  
(coupled to large reservoir)
- ↓ isentropic cooling  
(by rapid expansion)
- ↑ isentropic heating  
(by rapid compression)

## The Thermodynamic Limit of the Carnot Cycles

$$\delta S = \frac{\delta Q_h}{T_h} + \frac{\delta Q_c}{T_c} \geq 0 \quad (8)$$

where

$\delta Q_h$  = thermal energy supplied to to the hot system

$T_h$  = temperature of the hot system

$\delta Q_c$  = thermal energy supplied to the cold system

$T_c$  = temperature of the cold system

$\delta Q < 0$  describes extraction of energy from the system.

## The Thermodynamic Limit of a Geothermal Heating System

Hot system: heating system,  $\delta Q_h > 0$


Cold system: geothermal reservoir,  $\delta Q_c < 0$


Thermodynamic limit of the heat pump (Eq. 8) written in terms of total power  $P_{\text{tot}}$  (to the heating system) and thermal power  $P_{\text{th}}$  (from the geothermal reservoir):

$$\frac{P_{\text{tot}}}{T_h} - \frac{P_{\text{th}}}{T_c} \geq 0 \quad (9)$$

The difference between  $P$  and  $P_{\text{th}}$  must be supplied as mechanical (electrical) power by the compressor,  $P_{\text{el}} = P_{\text{tot}} - P_{\text{th}}$ .

## The Thermodynamic Limit of a Geothermal Heating System



$$\frac{P_{\text{tot}}}{T_h} - \frac{P_{\text{tot}} - P_{\text{el}}}{T_c} \geq 0 \quad (10)$$


$$P_{\text{tot}} \leq \frac{T_h}{T_h - T_c} P_{\text{el}} \quad (11)$$

## The Coefficient of Performance

$$\text{COP} = \frac{P_{\text{tot}}}{P_{\text{el}}} \leq \frac{T_h}{T_h - T_c} \quad (12)$$

## The Upper Thermodynamic Limit of the COP



## The COP of Real Heat Pumps

- Real heat pumps achieve a significantly lower performance than the thermodynamic limit, e. g., COP = 5 is very good for  $T_h = 35^\circ\text{C}$  and  $T_c = 0^\circ\text{C}$  (instead of COP<sub>max</sub> = 8.8).
- Data sheets with the COP for different temperatures are provided by some suppliers.
- If not, use the concept of relative efficiency.

## The Relative Efficiency

General concept:

$$\eta = \eta_{\max} \eta_{rel} \quad (13)$$

where

$\eta$  = total efficiency (output/input)

$\eta_{\max}$  = theoretically possible maximum efficiency

$\eta_{rel}$  = relative efficiency of the specific device

For a heat pump:  $\eta_{\max}$  defined by the thermodynamic limit  
(inverse Carnot Cycle)



## The Relative Efficiency

Two ways to apply the concept of relative efficiency to a heat pump:

Electrical power  $\rightarrow$  total power:

$$\text{COP} = \frac{P_{\text{tot}}}{P_{\text{el}}} = \eta_{\text{rel}} \left( \frac{P_{\text{tot}}}{P_{\text{el}}} \right)_{\text{max}} = \eta_{\text{rel}} \frac{T_h}{T_h - T_c} \quad (14)$$

Electrical power  $\rightarrow$  thermal power:

$$\frac{P_{\text{th}}}{P_{\text{el}}} = \eta_{\text{rel}} \left( \frac{P_{\text{th}}}{P_{\text{el}}} \right)_{\text{max}} = \eta_{\text{rel}} \left( \frac{P_{\text{tot}} - P_{\text{el}}}{P_{\text{el}}} \right)_{\text{max}} \quad (15)$$

$$= \eta_{\text{rel}} \left( \frac{T_h}{T_h - T_c} - 1 \right) = \eta_{\text{rel}} \frac{T_c}{T_h - T_c} \quad (16)$$

## The Relative Efficiency



$$\text{COP} = \frac{P_{\text{tot}}}{P_{\text{el}}} = 1 + \frac{P_{\text{th}}}{P_{\text{el}}} = 1 + \eta_{\text{rel}} \frac{T_c}{T_h - T_c} \quad (17)$$


- The second concept is physically better.



Use it in the following.

- Typical value:  $\eta_{\text{rel}} \approx 0.5$  for good heat pumps

## Typical COP of a Good Heat Pump ( $\eta_{rel} = 0.5$ )



## Actual Energy Prices in Germany

Energy source	Price [ $\frac{\text{ct}}{\text{kWh}}$ ]
wood	6
gas	6
oil	7
electricity	28



Heat pump driven by electricity makes sense only if  $\text{COP} \gtrsim 4.5$  in the mean.

Alternative: gas heat pump

## The Heat Pump in Geothermal Calculations

- $P_{\text{tot}}$  given by the heating demand
- $P_{\text{th}}$  required for the calculation of the geothermal system
- $P_{\text{el}}$  required for calculating the costs of heating

$$P_{\text{el}} = \frac{P_{\text{tot}}}{1 + \eta_{\text{rel}} \frac{T_c}{T_h - T_c}} \quad (18)$$

$$\begin{aligned} P_{\text{th}} &= P_{\text{tot}} - P_{\text{el}} = P_{\text{tot}} - \frac{P_{\text{tot}}}{1 + \eta_{\text{rel}} \frac{T_c}{T_h - T_c}} \\ &= \frac{P_{\text{tot}}}{1 + \frac{1}{\eta_{\text{rel}}} \frac{T_h - T_c}{T_c}} \end{aligned} \quad (19)$$