

Geothermics and Geothermal Energy

Closed Geothermal Systems

Stefan Hergarten

Institut für Geo- und Umweltwissenschaften
Albert-Ludwigs-Universität Freiburg




Principle

- Fluid circulates in a closed heat exchanger.
- Heat is transported to the fluid by heat conduction.
- Heat transport in the surrounding rock or soil by heat conduction; in some cases also by advection (groundwater).

Fluids

- Water or alcohol-water mixtures.
- Water has the best properties (heat capacity, thermal conductivity, viscosity) as long as $T > 0^{\circ}\text{C}$.

Types of Geothermal Systems



Source: Ingolstädter Kommunalbetriebe (modified)

Limitation

Heat is transported to the heat exchanger by conduction.



Requires a temperature gradient toward the exchanger.



Temperature in the exchanger is lower than the undisturbed subsurface temperature.

Limitation


Temperature drop depends on

- thermal properties of the subsurface (mainly the thermal conductivity)
- properties of the exchanger (size, shape, material)
- extracted power



Production of electricity is economically not reasonable
(so far?).

Downhole Heat Exchangers (Borehole Heat Exchangers)




Source: Erdwärme21

Downhole Heat Exchangers (Borehole Heat Exchangers)



Source: Baublog: Villa Lugana in Teltow

Downhole Heat Exchangers (Borehole Heat Exchangers)



Source: Sliwa & Rosen (2015), *Sustainability*, 7(10), 13104, doi:10.3390/su71013104

Application of Downhole Heat Exchangers

Shallow heat exchangers ($d \lesssim 400$ m, $T \lesssim 25^\circ\text{C}$):

heating of buildings with the help of heat pumps

Deep heat exchangers ($d \gtrsim 1000$ m, $T \gtrsim 40^\circ\text{C}$):

direct heating

- down to depths of about 3000 m so far (coaxial type only)
- mostly reuse or deepen abandoned hydrocarbon boreholes
- economically still questionable

Ground Heat Collectors



Source: www.bauweise.net

Ground Heat Collectors




Source: Rehau AG & Co

Geothermal Baskets



Source: Heizungsjournal

Geothermal Energy Pillars



Sources: Energy Systems Research Unit, University of Strathclyde; Stober & Bucher, Geothermie

Superposition of Solutions

The heat conduction equation is linear.



Can be solved by superposing individual components:

$$T(\vec{x}, t) = T_m(\vec{x}) + T_y(\vec{x}, t) + T_1(\vec{x}, t) + T_2(\vec{x}, t) + \dots \quad (1)$$

with

$T_m(\vec{x})$ = steady-state geotherm

$T_y(\vec{x}, t)$ = natural seasonal variation

$T_i(\vec{x}, t)$ = temperature change caused by the i^{th} heat exchanger

Use T instead of T_i in the following.

Analytical Approximations

All three components can be approximated by analytical solutions of the heat conduction equation reasonably well in most cases.



No need for numerical simulations and / or specific software

Analytical solutions use

- symmetries for reducing the spatial dimension (mainly from 3 to 1) and
- scaling properties (length vs. time).

Cylindrical Symmetry

$T(x, y, z, t)$ only depends on $r = \sqrt{x^2 + y^2}$ and t .


Limitations:

- Fluid temperature in the heat exchanger must increase with the geothermal gradient.



Only applicable to shallow boreholes and to deep coaxial heat exchangers under specific conditions.

- Seasonal temperature variation in the upper region cannot be taken into account.
- Borehole length l must be much larger than $L(t) = \sqrt{\kappa t}$.



Analogy to Darcy Flow

Pressure around an injection or extraction well:

$$p(r, t) = \frac{\eta}{4\pi kl} Q E_1 \left(\frac{r^2}{4L(t)^2} \right) = \frac{\eta}{4\pi kl} Q E_1 \left(\frac{r^2}{4\tilde{\kappa}t} \right) \quad (2)$$

with

η = dynamic viscosity of the fluid [Pa s]

k = hydraulic permeability [m²]

l = length of the well [m]

Q = rate of injection [$\frac{\text{m}^3}{\text{s}}$]

$\tilde{\kappa}$ = diffusivity [$\frac{\text{m}^2}{\text{s}}$]

and the exponential integral $E_1(v) = \int_v^{\infty} \frac{e^{-x}}{x} dx$

Analogy to Darcy Flow

Equivalence of properties:

	Darcy flow	Heat conduction
variable	p	T
parameters	$\rho_f \frac{k}{\eta}$	λ
	S	ρc
	$\tilde{\kappa} = \frac{\rho_f k}{\eta S}$	$\kappa = \frac{\lambda}{\rho c}$
balanced property	mass	energy
total input / output	$\rho_f Q$	P (power)



$$T(r, t) = \frac{P}{4\pi\lambda l} E_1 \left(\frac{r^2}{4L(t)^2} \right) = \frac{P}{4\pi\lambda l} E_1 \left(\frac{r^2}{4\kappa t} \right) \quad (3)$$


Solution for Constant Heat Extraction

Define $P_l = -\frac{P}{l}$ as the extracted power per borehole length.



$$T(r, t) = -\frac{P_l}{4\pi\lambda} E_1\left(\frac{r^2}{4L(t)^2}\right) = -\frac{P_l}{4\pi\lambda} E_1\left(\frac{r^2}{4\kappa t}\right) \quad (4)$$

Solution for Step-Like Heat Extraction



Solution for Step-Like Heat Extraction

Superposition of several heat exchangers switched on at different times:

Month #	P_I [$\frac{W}{m}$]	Exchanger #	Start time [mon]	P_I [$\frac{W}{m}$]
1	0.7	1	0	0.7
2	2.7	2	1	2.0
3	10.2	3	2	7.5
4	19.7	4	3	9.5
5	29.5	5	4	9.8
6	35.5	6	5	6.0
7	32.3	7	6	-3.2
8	28.0	8	7	-4.3
...

Solution for Step-Like Heat Extraction


Formally:

$$P_l(t) = \begin{cases} 0 & \text{for } t < t_0 \\ P_{l,i} & \text{for } t_{i-1} \leq t < t_i \end{cases} \quad (5)$$



$$\begin{aligned} T(r, t) = & -\frac{P_{l,1}}{4\pi\lambda} E_1\left(\frac{r^2}{4\kappa(t-t_0)}\right) \\ & - \frac{(P_{l,2} - P_{l,1})}{4\pi\lambda} E_1\left(\frac{r^2}{4\kappa(t-t_1)}\right) \\ & - \dots \\ & - \frac{(P_{l,n+1} - P_{l,n})}{4\pi\lambda} E_1\left(\frac{r^2}{4\kappa(t-t_n)}\right) \end{aligned} \quad (6)$$

Solution for Step-Like Heat Extraction



The Thermal Resistance

Behavior for $r \ll L(\delta t)$ is determined by the actual heat extraction P_I if P_I has been constant for a time interval δt :

$$T(r, t) \approx -\frac{P_I}{4\pi\lambda} E_1\left(\frac{r^2}{4L(\delta t)^2}\right) + f(t) \quad (7)$$

$$\approx \frac{P_I}{4\pi\lambda} \left(\ln\left(\frac{r^2}{4L(\delta t)^2}\right) + 0.5772 \right) + f(t) \quad (8)$$

where the function $f(t)$ depends on the history of P_I .

The Thermal Resistance

Consider two boreholes of different radii r_1 and r_2 .



$$T(r_1, t) - T(r_2, t) = \frac{P_I}{4\pi\lambda} \left(\ln \left(\frac{r_1^2}{4L(\delta t)^2} \right) - \ln \left(\frac{r_2^2}{4L(\delta t)^2} \right) \right) \quad (9)$$

$$= \frac{P_I}{2\pi\lambda} \ln \left(\frac{r_1}{r_2} \right) \quad (10)$$

for $r_1 \ll L(\delta t)$ and $r_2 \ll L(\delta t)$.



Temperature difference is proportional to the actual P_I .

The Thermal Resistance

Similar result for the borehole's filling and the walls of the heat exchanger:

$$T_f(t) = T(r_b, t) - R P_l \quad (11)$$

where

$T_f(t)$ = temperature of the fluid in the heat exchanger

r_b = radius of the borehole

R = resistance of the borehole / heat exchanger

- Borehole resistance depends on the geometry (single U-tube, double U-tube, coaxial) and on the material used for filling.
- Typical values for double U-tube heat exchangers:
 - $R \approx 0.1 \frac{\text{mK}}{\text{W}}$ (standard filling)
 - $R \approx 0.08 \frac{\text{mK}}{\text{W}}$ (thermally improved filling)

Including the Thermal Resistance in the Calculation

Define an apparent borehole radius r_a in such a way that

$$T_f(t) = T(r_a, t) \quad (12)$$



$$T(r_b, t) - T_f(t) = R P_l = T(r_b, t) - T(r_a, t) = \frac{P_l}{2\pi\lambda} \ln\left(\frac{r_b}{r_a}\right) \quad (13)$$

with

$$R = \frac{1}{2\pi\lambda} \ln\left(\frac{r_b}{r_a}\right) \quad (14)$$



$$r_a = r_b e^{-2\pi\lambda R} \quad (15)$$

The Thermal Resistance of a Single Tube

Assume a single tube of outer radius r_b , wall thickness d and thermal conductivity λ_t (in general smaller than λ of the surrounding rock or soil).



$$R = \frac{1}{2\pi\lambda_t} \ln\left(\frac{r}{r-d}\right) \quad (16)$$

or in terms of an apparent radius r_a :

$$r_a = r_b e^{-2\pi\lambda R} = r_b e^{-\frac{\lambda}{\lambda_t} \ln\left(\frac{r_b}{r_b-d}\right)} = r_b \left(\frac{r_b-d}{r_b}\right)^{\frac{\lambda}{\lambda_t}} \quad (17)$$

Principle


Measure how feeding thermal energy into the geothermal system changes the temperature.

Simplest Implementation

- ① Let water circulate until its temperature is in equilibrium with the surrounding rock / soil.
- ② Supply a well-defined thermal power to the water cycle and measure the temperature of the returning water (if possible, also in the borehole at different depths) through time.

Simplest Implementation

Schematic Diagram of Thermal Response Test Equipment Setup



Source: Synergy boreholes and systems ltd.


Result

- Thermal parameters of the surrounding rock / soil and of the borehole.
- Reveals whether the thermal properties are as assumed (e. g., whether filling has been done correctly).


Limitation

Can only be applied after the heat exchanger has been installed.

Example of a Response Curve Without Thermal Resistance



Example of a Response Curve Without Thermal Resistance



Modeling Approaches

- Infinite horizontal plane
- Set of parallel pipes

Too small



Source: www.bauweise.net


Large enough




Source: Rehau AG & Co

Modeling as a Set of Parallel Pipes

Typical configuration



Simplified model




- Parallel horizontal pipes of infinite length




Theory of shallow downhole heat exchangers can be applied.

- Assume the same power per length for all pipes.


10 Parallel Pipes With 1 m Spacing in 1.5 m Depth After 3 Days



10 Parallel Pipes With 1 m Spacing in 1.5 m Depth After 1 Month



10 Parallel Pipes With 1 m Spacing in 1.5 m Depth After 1 Year



Limitations

- Temperatures of the pipes are not the same.



Same P_l for each pipe is not correct.




Not a big problem, use mean temperature.

- Surface temperature is affected by the heat collector as if there was no surface, while solar radiation and rapid heat transport in the atmosphere keep the temperature more constant in reality.




Simplest model: keep surface temperature constant.


10 Parallel Pipes With 1 m Spacing in 1.5 m Depth After 3 Days



10 Parallel Pipes With 1 m Spacing in 1.5 m Depth After 1 Month



10 Parallel Pipes With 1 m Spacing in 1.5 m Depth After 1 Year



Computing the Average Temperature of Parallel Pipes

Assume n parallel pipes in a depth d below the surface and a horizontal spacing s .

Distance r	Sign	Mean number
r_a	+	1
s	+	$2\left(1 - \frac{1}{n}\right)$
$2s$	+	
$3s$	+	
...
$(n-1)s$	+	

Distance r	Sign	Mean number
$2d$	-	1
	-	
	-	
	-	
...
	-	

Main Difference Toward Shallow Heat Exchangers

Significant variation in temperature along the borehole.



Only coaxial heat exchangers can be used.

Main Field of Application

Direct (district) heating without heat pumps.

Energy Balance for the Fluid in the Heat Exchanger

Steady-state energy balance for the fluid:

$$\rho_f c_f Q T_f - \rho_f c_f Q T_f + P_l d = 0 \quad (18)$$

where

ρ_f = density of the fluid


c_f = specific heat capacity of the fluid

Q = flow rate [$\frac{m^3}{s}$]

T_f = fluid temperature



$$f \frac{\partial T_f}{\partial z} = P_l \quad \text{where} \quad f = \quad (19)$$



Numerical Implementation

Switch the power per length at time t to a value $P_l(z, t)$.

Use a difference quotient for Eq. 19:

$$f \frac{T_f(z, t + \delta t) - T_f(z - \delta z, t + \delta t)}{\delta z} = \frac{P_l(z, t) + P_l(z - \delta z, t)}{2} \quad (20)$$

Numerical Implementation

Fluid temperature according to Eq. 6:

$$\begin{aligned} T_f(z, t + \delta t) &= T_m(z) + T(z, t + \delta t) \\ &= T_m(z) + T_0(z, t + \delta t) \\ &\quad - \frac{P_l(z, t)}{4\pi\lambda} E_1\left(\frac{r_a^2}{4\kappa\delta t}\right) \end{aligned} \quad (21)$$

where $T_0(z, t + \delta t)$ is the temperature that would occur if we switched $P_l(z, t)$ to 0.



2 equations for $T_f(z, t + \delta t)$ and $P_l(z, t)$